

CR9-RX **User Manual**

1. GENERAL INFORMATION

It is a slim Wiegand output proximity reader compatible with any Wiegand input controller. The reader is fully potted, and can function at extreme temperatures (-40°C), which allows it is capable to be mounted either indoor or outdoor.

EM version: read 125KHz EM card.


EM+HID version: read 125KHz EM + HID cards

2. SPECIFICATIONS

2. 0. 2007.1.10.10	
Version	EM; EM+HID
Frequency	125KHz
Card type	
Operation voltage	
Standby current	≤25mA
Read range	0-6 cm
Wiegand output	26bits
	up to 58 bits on request
Operating temperature (°C)	40+60
Operating humidity	10% to 95% RH
Color	black (white optional)
ColorIndex of protection	IP66
Dimensions	103x48x20 mm
Net wight	
Shipment weight	<u> </u>

3. INSTALLATION

- Drill 2 holes (a, C) on the wall for the screws and one hole for the cable;
- Knock the rubber bungs to the holes (A, C);
- Fix he back cover on the wall with 2 screws; Thread the cable though the cable hole (B);
- Attach the unit to the back cover.






Wiring

Color	Function	Notes
Red	Power	+DC (9-18 V DC)
Black	GND	Ground
Green	D0	Data 0
White	D1	Data 1
Brown	LED	Green LED Light Control
Yellow	Buzzer	Buzzer Control

Remarks: Brown and yellow wires are optional connections.

Connection Diagram



4. FUNCTIONS TABLE SHEET

Read Card	The LED light will turn into Green, and the buzzer sounds a beep, at the meantime, the reader outputs the Wiegand signal
External LED Control	When the input voltage for LED is low, the LED will turn into Green
External Buzzer Control	When the input voltage for Buzzer is low, the Buzzer will sounds
Wiegand Data Output	Wiegand 26-44, 56, 58 bits available upon request, factory default setting is Wiegand 26bits.

5. PACKING LIST

Reader: 1 pc Manual: 1 pc Screw driver: 1 pc Wall fixing plugs: 2 pcs Self tapping srews: 2 pcs



6. ICONTROL CONTACTS

ICONTROL SIA 1B, Balta iela, LV-1055, Riga, Latvia

E-mail: info@icontrol.lv

Phone: +37166181894+37124422922

www.icontrol.lv



